

JODALE-PERRY

MOUNTING INSTRUCTIONS

MODEL: 223D TORO
CODE: JDP ROPS

INCLUDES:
MOUNTING INSTRUCTIONS
PARTS LIST

JDP
BUILT FOR LIFE

Parts List

- 01 - Front mounting bracket
- 02 - Rear mounting bracket (L & R)

Bolt list:

- 2 - 3/8" x 1" Bolts, nuts, washers
- 4 - 3/8" x 1 1/2" Bolts, lockwashers,
flatwashers
- 4 - 1/2" x 2 1/2" Bolts, nuts, washers
- 4 - 1/2" x 3" Bolts, nuts, washers

Miscellaneous List:

- 4 - Rubber mounts

1. Remove the deck-to-tractor weight transfer system from the unit.
2. Take the front mounting bracket (1) and position it against the front of the platform. Line up the holes in the platform with those in the bracket, then reattach the deck-to-tractor system to the unit using the 3/8" x 1 1/2" bolts, flatwashers, and lockwashers supplied. Ensure that the front mounting bracket is level. Using the two side holes as guides drill two 7/16" dia. holes through the sides of the platform. Then bolt the bracket loosely to the unit using the 3/8" x 1" bolts, nuts, and lockwashers provided. (see diagram #1)
3. ONLY NOW ARE YOU READY TO MOUNT THE ROPS. Place rubber mounts onto the front mounting bracket tabs. Lift the ROPS directly above the unit using the mounting bolts located near the top of the cab. Slowly lower the ROPS until the front mounts rest solidly on the rubber mounts. Then, loosely bolt the ROPS to the front mounting bracket using the 1/2" x 3" bolts, nuts, and washers supplied. (see diagram #2)
4. Adjust the height of the rear ROPS mounts until the ROPS is level. Then bolt the rear mounting brackets (2) snugly to the ROPS as indicated in diagram #2. Ensure that the brackets are level, then using the bracket holes as a guide drill two 9/16" dia. holes into each side of the unit. CAUTION: Before drilling check to see that no electrical wires, hydraulic or cooling system hoses will be damaged by drilling through the frame. Then bolt the brackets to the unit using the 1/2" x 2 1/2" bolts, nuts, and lockwashers supplied. (see diagram #3)
5. Fasten all mounting bolts to ensure that the ROPS is snugly attached to the unit.
6. Operate the hydrostatic foot pedal. If the pedal contacts the ROPS frame, cut the pedal to ensure normal operation.
7. Remove the shipping brackets from the side entrances.
8. If applicable, connect the electrical power wire located at the bottom of one of the ROPS frame rear tubes to the ignition switch, using the 30 amp. in-line fuse provided. If the ignition switch is inaccessible connect the wire to another 12-volt source.

Mounting Instructions

