

Toro 3000 ROPS

Parts List & Mounting Instructions

Jodale • Perry

Printed: 2001/02

Toro 3000 ROPS Mounting Instructions

Standard Parts List

Qty	Description	Photo
L&R	Rear Mount Brackets	

NOTE: All references to left and right are taken from the operator's point of view when he/she is sitting in the driver's seat.

Toro 3000 ROPS Mounting Instructions

Standard Bolts List

Qty	Description
4	Mount, Isolator, ½" x 3"
4	Washer, Rubber, ½" x 2 ½"
4	Washer, Steel, ½" x 2 ½"
4	Washer, Lock, ½"
2	Washer, Flat, 9/16" x 1 3/8"
2	Bolt, Hex, ½" x 3", Grade 8, Yellow Dichrome
2	Bolt, Hex, ½" x 4", Grade 8, Yellow Dichrome
4	Nut, Hex, ½", Grade 8, Yellow Dichrome
2	Bolt, Hex, 7/16" x 4 ½" (lift bolt)

NOTE: All references to left and right are taken from the operator's point of view when he/she is sitting in the driver's seat.

Toro 3000 ROPS Mounting Instructions

1. Remove 2-Post ROPS guard, and keep ROPS hardware to be re-used.
2. Take left rear bracket and slide over two-post ROPS sleeve and loosely tighten with existing ROPS hardware (see Figure 1)
3. Repeat step 2 for right rear bracket.
4. Raise ROPS with lift bolts provided and position ROPS over tractor and slowly lower. Fasten rear bracket to ROPS mount with hardware provided, two $\frac{1}{2}$ " x 3" hex bolts, $\frac{1}{2}$ " lock washers, $\frac{1}{2}$ " hex nuts, rubber flat washers, and $\frac{1}{2}$ " x 2 $\frac{1}{2}$ " steel flat washers.
5. Lower front of ROPS so that front bracket is on front platform. Mark and drill two $\frac{9}{16}$ " holes through operator platform. Use remaining hardware to fasten front mounts down, using the $\frac{9}{16}$ " x 1 $\frac{3}{8}$ " flat washers below platform as shown in Figure 2.



Figure 2



Figure 1

NOTE: All references to left and right are taken from the operator's point of view when he/she is sitting in the driver's seat.