Toro

3500 Sunshade

Parts List & Mounting Instructions

Jodale • Perry

Printed: 2003/07

Toro 3500 Sunshade Mounting Instructions

Standard Parts List

Qty	Description	Photo
L&R	Rear Mount Plate Brackets	

Standard Bolts List

8	Bolt, Hex, 3/8” x 3”, Yellow Dichrome
8	Nut, Flange, 3/8”, Yellow Dichrome

Mount Instructions

NOTE: The sunshade canopy is for weather/sun protection only.

1. Remove the canopy from the shipping pallet.

2. Take the rear bracket mounting plates and line up the left plate with the left mounting plate of the canopy sub-frame. Bolt the outer two bolts together with the 3/8” x 3” hex bolts and flange nuts. The inner two must not be connected until the bracket is slid over the 2-post ROPS. Ensure that there is more than 3” between the mounting plates so that there is adequate room for the 2-post. Repeat for the right side and the outer 2 fasteners.

3. Lift the canopy over the 2-post and slide the plates with the ROPS between. Take the remaining four fasteners and attach to the mounting bolts. Torque all of the 3/8” fasteners 42 ft-lbs.

NOTE: All references to left and right are taken from the operator’s point of view when he/she is sitting in the driver’s seat.